

PRELIMINARY OPERATION MANUAL - QL DISK

JOB NAME : SuperBASIC
 IDENTIFIER : 00000000
 LENGTH : 00000000 (in bytes)
 ENTRY POINT : 00000000 (address)
 OWNER JOB : 00000000
 PRIORITY : 20 (0 to 127)
 WAITING JOB : 00
 STATUS : 0000
 EXCEPTION VECTOR : 00000000

10.1.0 Command : JOBS
 Syntax : JOBS [#ch]
 Action : Lists the parameters of each job currently in the QL.

10.2.0 Command : PRIOR
 Syntax : PRIOR jobid, PR
 Parameters : jobid = task number obtained by JOBS.
 PR = new priority assignment of the task.
 Action : Changes priority of defined job.

10.3.0 Command : ACTIV
 Syntax : ACTIV jobid, PR, TMOUT
 Parameters : jobid = task number obtained by JOBS.
 PR = new priority assignment of the task.
 TMOUT =

10.4.0 Command : SUSJOB
 Syntax : SUSJOB jobid, flagA, TMOUT
 Parameters : jobid = task number obtained by JOBS.
 PR = new priority assignment of the task.
 flagA =
 TMOUT = length of task suspension, in units of 20ms
 Action : Suspends an active job.

10.5.0 Command : RELJOB
 Syntax : RELJOB jobid
 Parameter : jobid = task number obtained by JOBS.
 Action : To re-activate jobid previously suspended.

10.6.0 Command : RMVJOB
 Syntax : REMJOB jobid, err_number
 Parameters : jobid = task number obtained by JOBS.
 err_number = Error code
 Action :

11.0.0 TIME

11.1.0 Command : CLOCK_ON
 Syntax : CLOCK_ON
 Parameters : None
 Action :
 NOTE :

11.2.0 Command : CLOCK_OFF
 Syntax : CLOCK_OFF
 Parameters : None
 Action :
 NOTE :

12.0.0 SYSTEM PARAMETER CONTROLS