

PRELIMINARY OPERATION MANUAL - QL DISK

APPENDIX 2

Table of Error messages

Message	Code
Not Complete	-1
Invalid Job	-2
Out of memory	-3
Out of range	-4
Buffer overflow	-5
Channel not open	-6
Not found	-7
File already exists	-8
In use	-9
End of file	-10
Drive full	-11
Bad name	-12
Xmit error	-13
Format failed	-14
Bad parameter	-15
Bad or changed medium	-16
Error in expression	-17
Overflow	-18
Not implemented	-19
Read only	-20
Bad line	-21
It's OK	0
Empty drive	1
Drive not on line	2
Read/write error	3
Not standard format	4
Double-sided media	5
File still open	6